

Suorin Ace

Please save this manual and read it fully before you start using this product as it contains important information.

User Manual

V2020-08

Please read this manual carefully before use.




Length	71mm
Width	45mm
Height	16mm
Weight	80g

Specifications

Coil Resistance	1.0 Ω
Pod Capacity	2.0ml
Battery Capacity	1000mAh
Max Output Current	5A
Max Output Wattage	15W
Charging Current	1.0A
Charging Time	50 Minutes
Material	Zinc Alloy + Plastic

Components



Operation Guide

How to fill with e-liquid

Step 1 Open the silicone plug



Step 2
Fill the e-liquid in and wait 5-8 minutes.



Step 3 Install the cartridge



Power On/Off

Press the fire button 5 times continuously to turn on/off the device.

Battery Indicator

Light indicator while vaping
Red<30%, 30%<Blue<70%, 70%<Green

Light indicator while charging Red<30%, 30%<Blue<70%, 70%<Green

Notice: When the device battery is completely drained, it will take a few minutes to continue charging to see the light on.Please use certified adapter product for charging.

Protection Functions

Open Circuit Indicator:

When no pod is installed or open circuit, the battery indicator light will flash 8 times.

Short Circuit and Overcurrent Protection:

When resistance is lower than $0.4\,\Omega$, it will be stopped. The battery indicator light will flash 5 times.

Low Voltage Protection:

When the battery voltage is lower than 3.3v, or the battery voltage is lower than 3.1v when vaping, it will be stopped. The RED indicator light will flash 3 times.

Vaping Timeout Protection

When vaping time exceeds 5 seconds, it will be stopped. The indicator light will flash 10 times.

Overcharge Protection

When the battery voltage is full, the charging will be turned off to prevent the battery from overcharging. The GREEN light is always on.



- Let the cartridge stand up-straight for 5-8 minutes to make sure. the cotton is fully saturated.
- 2. This product is available for Suorin Ace cartridge and Suorin Shine cartridge
- Dispose of the contents/container in accordance with local laws.
- 4. It is not recommended for minors and non-emokers

Troubleshooting

- 1. If the device's battery cannot be charged, check that the charger cord is fully connected to the Type-C port.
- 2. If aerosol is not emitted normally when puffing on the device:
 - a. Confirm that the cartridge is properly in place and tightly connected to the device.
 - b. Confirm the device is under "on" state.
 - Confirm that sufficient e-liquid remains in the cartridge. If not. refill the cartridge.
 - Confirm that adequate charge remains in the battery.

If not, please charge as soon as possible. If the product still does not work, email our customer service center at info@suorin.com for further assistance



SAFETY WARINGS:

- Nicotine is a highly addictive and toxic substance. Use care when re-filling and handling this device and refilling the cartridges with e-liquid.
- For use with nicotine-containing e-liquids only. Not for use with high viscosity liquids, waxes, or oils, including THC oils, cannabidiol oils, or other controlled substances. Use with such substances may lead to malfunction of or damage to the product and can result in severe illness or injury.
- When refilling the cartridge with nicotine-containing e-liquid, avoid contact with skin and eves. If accidental contact with the skin or

- eyes occurs, rinse with plenty of water and contact a medical professional if irritation occurs or persists.
- Do not use this product if it appears damaged, has been modified, disassembled, or immersed in water.
- When traveling on an airplane or other pressurized environment, remove the cartridge from the device and store it upside-down to avoid leaking of e-liquid from the cartridge.
- Do not use this product with an empty cartridge, as such may result in increased exposure to harmful substances.
- Keep the device, all cartridges, and all e-liquid containers out of the reach of children and pets, as this product presents both a poisoning and choking hazard.
- In the event of accidental ingestion of e-liquid, seek help from your local poison control center immediately (in USA region please contact 1-800-222-1222).
- Only charge the device indoors.
- Do not use this device or its cartridges with cartridges, batteries, coils, chargers, or other replacement parts from other manufacturers, as such may lead to an increased risk of explosion, fire, or nicotine poisoning, and can result in severe illness, injury, or death. Useonly Suorin-brand compatible replacement parts.
- Do not attempt to disassemble or modify this product in any way, as such may lead to malfunction of or damage to the product, increased risk of explosion, fire, or nicotine poisoning, and can result in severe illness. injury. or death.
- Do not use this product when flammable materials, liquids, or gases, including oxygen, are present or in use.



★ HEALTH WARINGS:

- This product is intended for use by existing cigarette smokers. only and should not be used by non-smokers or individuals under the legal age to purchase e-cigarettes or vapor products in their respective jurisdictions.
- . This product should not be used by individuals with high blood pressure, heart disease, diabetes, respiratory illness or disease. asthma gastritis gastric ulcer duodenal ulcer gastro-esophageal reflux disease or who are allergic to any of the listed ingredients.

This product should not be used by pregnant, suspect they may be pregnant or plan tobecome pregnant, or who are breastfeeding. Exposure to nicotine is harmful to fetal and infant development.

- You should discontinue use of this product and seek the attention of a medical professional if you feel dizzy, faint, or experience difficulty breathing while or immediately after using this product.
- Possible effects of nicotine consumption include: Coughing, headache, irritation of the mouth and throat, (nasal congestion, aphthous ulcers, sore throat, anxiety, insomnia, depression, discomfort, nausea, dry mouth, heartburn, aching joints, diarrhea, meteorism, allergy skin eruption, shortness of breath, labored breath, tightness of the chest, swelling of the face, tongue and lips), feeling thirsty, hiccups, chest pain, fever, irregular or increased heartbeat, dizziness, and sleepiness,

Seek the advice of a medical professional if you experience any of these symptoms.

 Possible symptoms of a nicotine overdose include: nausea, salivation. abdominal pain, diarrhea, sweating, headache, dizziness, hearing problems, weakness, and palpitation,

Discontinue use and seek immediate medical attention if you experience any of these symptoms while or shortly after using this product.

Shenzhen Youme Information Technology Co.,Ltd.


E-mail:info@suorin.com

www.suorin.com

Add:201, Building B, Dianlian technology building, Nanhuan Avenue, Mashantou Community, Matian street, Guangming District, Shenzhen







- Please let the cartridge stand for 5-8 minutes after filling e-liquid. Make sure the cotton is fully saturated.
- It is recommended to change a new coil after filling e-liquid for 5-8 times or within 7 days after e-liquid filling.